


APC Error

E×× • A×× • M××



E×× • A×× • M×× error

When APC error occurs

APC(hydraulic pump control) or electric parts error occurs.
Please read error code (s).